



RACS 2520i SET

Pozice	Popis	Počet
RACS2520_01	Motor rear cover	1
RACS2520_02	Motor shell	1
RACS2520_03	Brushless motor	1
RACS2520_04	Motor gear	1
RACS2520_05	Left guide rail	1
RACS2520_06	Right guide rail	1
RACS2520_07	Wheel	1
RACS2520_08	Right housing	1
RACS2520_09	Self lock button	1
RACS2520_10	Spindle lock spring	1
RACS2520_11	Swich trigger	1
RACS2520_12	Self lock spring	1
RACS2520_13	Screw	3
RACS2520_14	PCBA	1
RACS2520_15	Heat sink	1
RACS2520_16	Big gear	1
RACS2520_17	Semi-circle key	1
RACS2520_18	Output shaft	1
RACS2520_19	Anti dust	1
RACS2520_20	Bearing	2
RACS2520_21	Right housing	1
RACS2520_22	Screw	19
RACS2520_23	Anti dropping sprocket	1
RACS2520_24	Circlip	2
RACS2520_25	Screw	3
RACS2520_26	Oil output seal ring	1
RACS2520_27	Lock knob	1
RACS2520_28	Lock knob base	1
RACS2520_29	Tension knob	1
RACS2520_30	Right side cover	1
RACS2520_31	Brake spring	1
RACS2520_32	Brake rotate arm	1
RACS2520_33	Tension bease	1
RACS2520_34	O type ring	2
RACS2520_35	Screw	3
RACS2520_36	Oil tube connecter	1
RACS2520_37	Screw	4
RACS2520_38	Tension plate	1
RACS2520_39	Brake locate plate	2
RACS2520_41	Screw	1
RACS2520_43	Brake plate	1
RACS2520_44	Front handle	1
RACS2520_45	Bar cover	1
RACS2520_46	Oil tank cap seal ring	1

RACS2520_47	Oil tube connecter	2
RACS2520_48	Clip	1
RACS2520_49	Oil pump	1
RACS2520_50	Screw	11
RACS2520_51	Oil tube seal ring	1
RACS2520_52	Oil tank	1
RACS2520_53	Sponge	1
RACS2520_54	Single direction vavle	1
RACS2520_55	O type ring	1
RACS2520_56	Anti falling board	1
RACS2520_57	Oil tank cap seal pad	1
RACS2520_58	Oil tank cap	1