



RAHT 5220 SET			
Pozice	Obj.číslo	Popis	Počet ks
1	RAHT5220-1	Left decoration cover	1
2	RAHT5220-2	Left housing	1
3	RAHT5220-3	Screw	10
4	RAHT5220-4	Battery pack	1
5	RAHT5220-5	Diode	1
6	RAHT5220-6	Pole	2
7	RAHT5220-7	Pole seat	1
8	RAHT5220-8	Left rotate handle	1
9	RAHT5220-9	Switch trigger	1
10	RAHT5220-10	Switch button spring	1
11	RAHT5220-11	Switch	1
12	RAHT5220-12	Rotate button spring	1
13	RAHT5220-13	Rotate button	1
14	RAHT5220-14	Right rotate handle	1
15	RAHT5220-15	Screw	5
16	RAHT5220-16	Square inductor	1
17	RAHT5220-17	Right housing	1
18	RAHT5220-18	Right decoration cover	1
19	RAHT5220-19	Screw	20
20	RAHT5220-20	Screw	8
21	RAHT5220-21	Auxiliary handle lower cover	1
22	RAHT5220-22	Handle button spring	3
23	RAHT5220-23	Auxilairy handle switch	1
24	RAHT5220-24	Switch	1
25	RAHT5220-25	Auxiliary handle upper handle	1
26	RAHT5220-26	Transparent cover	1
27	RAHT5220-27	Motor	1
28	RAHT5220-28	Motor gear	1
29	RAHT5220-29	Nut	2
30	RAHT5220-30	Speed box base	1
31	RAHT5220-31	Screw	2
32	RAHT5220-32	Small gasket	2
33	RAHT5220-33	Gear	1
34	RAHT5220-34	Big gear	1
35	RAHT5220-35	Trimmer blade assembly	1
36	RAHT5220-36	Gasket	2
37	RAHT5220-37	Long tube	2
38	RAHT5220-38	Gasket	2
39	RAHT5220-39	Screw	2
40	RAHT5220-40	Speed box cover	1
41	RAHT5220-41	Gear box blade assembly	1
42	RAHT5220-42	Blade sleeve	1
43	RAHT5220-43	Charger	1