



Spare parts list for REM3210			
No.	ERP	Name	QTY
1	J2470000138R	upper handle	1
2	Q699371PH02	down fixation	1
3	Q699866PH02	upper fixation	1
4	J1920000000R	nut/M5	1
5	Q440D72AH01	hook	1
6	J0010000276R	bolt/M5×16	1
7	J0010001270R	bolt/ST4×16F	5
8	Q699D88PH02	switchbox lower	1
9	Q000943A611	trigger	1
10	J6990370001R	trigger spring	1
11	D1A600J7001R	framework pin	1
12	J0010000049R	bolt/ST4*15	1
13	D6002001075R	capacitance/0.22μF/20AWG	1
14	D3035000017R	switch	1
15	J0010000730R	bolt/ST4×8/SUS304	1
16	J0200000171R	washer/ø4.2×ø11.3×0.5/SUS304	1
17	Q699D87PH02	switchbox upper	1
18	Q699007A611	button	1
19	A9490990001R	cable	1
20	D404F702002R	temperature	1
21	2AJ10002R	motor	1
22	J0150000412R	circlip/ø8.0	1
23	J0150000998R	clip washer/ø6.0	1
24	J0160000056	bearing/609Z	1
25	Z0800000030	washer	1
26	D5000100004R	impaction	1
27	Q402D960B25R	motor plate	1

28	J0010000896R	bolt/ST5×20	9
29	J0160000299R	bearing/6002 - RZ	1
30	A3402040001R	pulley insert mould	1
31	J2510000028R	Motor pulley	1
32	X9490940001R	belt/5PJ416	1
33	J0320000017R	star lock domed/ø7.0	4
34	Q949D68PH02	wheel	4
35	J0020000088R	bolt/ø8×20	1
36	J0030000019R	washer/ø8.0×ø21×1.5	1
37	J2420000117R	blade/40Mn	1
38	J0090000299R	front wheel axes	1
39	Q949438PH02	deck	1
40	J0090000271R	rear wheel axes	1
41	J3400320001R	adjust spring	4
42	J0010110059R	bolt/ST5×16	2
43	Q949F48PH02	tongue	1
44	J6990360002R	safety flap spring	1
45	Q699885P611	safety flap	1
46	G9490220001	filter	2
47	Q949614P611	motor cover	1
48	J0010001022R	bolt/ST4×16×1.3	2
49	Q2567411H33R	cable hook	1
50	J0020000005R	nut	2
51	J0150000044R	washer/ø15×ø6	2
52	J2470000140R	lower handle	1
53	A2564650040R	knob	2

54	J2470000139R	lower handle	1
55	J0020000070R	bolt/M6×45	2
56	Q699D86P611	grassbox handle	1
57	Q699D67PZA6	grassbox	2