





Spare parts list for REM4218			
Pos no	Reference	English name	dosage
1	8160A117134	Side cover stickers	1
2	8DAB42025D	Cross pan head self-drilling screw	2
3	8020A117106	Side cover	1
4	8020A117101	Chassis front cover	1
5	8342A117101	Tension spring	2
6	8020A122101	Front wheel cover	2
7	8NAE0813D	Non-metallic flange lock nut	4
8	8121A122101	The front wheel	2
9	8440A117101	Front axle components	1
10	8186A115101	Wheel clamps	4
11	8DAB42019D	Cross Pan head self tapping screw	8
12	8DAH04016D	Cross countersunk head screw	1
13	8001A122101	Raise the handle	1
14	8NAL0407D	The cross sinks a bolt	1
15	8990A117101	Raising mechanism assembly	1
15-1	8DAA05016D	Cross pan head screw	1
15-2	8202A117101	Back cover shaft washer	1
15-3	8342A117102	Center pin spring	1
15-4	8440A117103	Hinge components	1
15-5	8440A117104	Gear plate assembly	1
16	750010001	Plastic terminal set	1
17	750420001	Special public terminal	2
18	8416A117101	capacitance	1
19	8006A117101	chassis	1
20	8403A112101	Under the fan motor	1
21	8231A117101	Blade	1
22	8440A115104	Blade locking bolt	1
23	8261A115101	Blade wrench	1
24	8020A117102	Chassis cover	1
25	8DAB48019D	Cross Pan head self tapping screw	11
26	8160A117135	Cover labeling	1
27	8024A117101	The wind hood	1
28	8990A117102	Motor Assembly	1
28-1	8CAC17B	Type A shaft with the retaining ring	2
28-2	8403A115102	Electrical wind leaf	1
28-3	8DCY63038D	Outside the hexagon self-drilling screw	4
28-4	8401A117102	Electric mower motor Assembly	1
28-5	8160A117103	Motor sticker	1
28-6	750420002	Special female terminal	4
28-7	750010002	Plastic terminal set	2
29	8NAE0610D	Non-metallic nuts with flange	2
30	8087A117104	The push rod	1
31	8202A117101	Rear shaft washer	4
32	8184A217101	Pressure line boards	1
33	8007E014201	Line buckle	2
34	8160A117136	Rear door stickers	1
35	8DDP42016D	Cross pan head with pad self tapping screw	2
36	8990A117103	Casing back cover component	1
36-1	8020A117103	Casing back cover	1
36-2	8081A117103	Back cover shaft	1
36-3	8342A122102	Back cover torsional spring	1
37	8440A117102	Rear axle Assembly	1
38	8121A117102	Rear wheel	2
39	8020A117105	Rear wheel caps	2
40	8343A122101	Hang hook	1

41	8440E014204	Knob component	2
42	8SAC08045D	Round head square neck bolts	2
43	8331A115101	The push rod set	1
44	8087A117103	The push rod	1
45	8187A112101	Switch box mounting plate	1
46	8990A117104	Switch box component	1
46-1	8DAB42016D	Cross Pan head self tapping screw	20
46-2	8020A112104	Switch box to the left	1
46-3	8181A112102	Switch Spring Board	1
46-4	8342A112102	Switch button spring	1
46-5	8312A112102	Switch button	1
46-6	8044A112102	Switch the wrench	1
46-7	8020A112103	Switch box to the right	1
46-8	8042A115101	Switch	1
46-9	8184A217101	Line pressing board	2
46-10	8332A217101	Cable sheath	2
46-11	8422A117101	Motor cable	1
46-12	8422A115101	Power cord	1
46-13	750420001	Special public terminal	2
46-14	8332A115101	Casing top cover cable sheath	1
46-15	750010001	Plastic terminal blocks	1
47	8001A117102	Set grass cover handle	1
48	8990A117105	Set the grass cover components	1
48-1	8020A117107	Skylight covers	1
48-2	8106A117101	Set grass cover	1
48-3	8103A117101	Grass frame	1
48-4	8186A115101	Wheel clamps	4
48-5	8DAB42016D	Cross pan head self-drilling screw	8
48-6	8440A117105	Collecting bag assembly	1