



No.	ERP	English Name	Dosage
1	Q222F48PH02	Grass lesd board	1
2	Q197807P874	Instruction board for grass	1
3	Q195F44PH02	Grass box"s cover	1
4	Q636K20P611	Hand cover of grass box	1
5	Q636D86P611	Grass box"s hand	1
6	J0010000620R	Screw/ST4*16	22
7	Q284F49PH02	Left support"s cover	1
8	J0010001032R	Screw/M4*10	2
9	Q284F231H33R	Left-hande support	1
10	J2840360002R	Sypport spring	1
11	Q284F50PH02	Right-support cover	1
12	J0390000062R	Trigger pole	
13	Q284D87PH02	Left switch box	1
14	J2470000073R	Top hand	1
15	Q284F241H33R	Right-hand support	1
16	J2840360001R	Trigger spring	1
17	D3039000001R	Switch	1
18	Q284B700B25R	Cord wrap	1
19	Q2849430H33R	Trigger	1
20	Q284D88PH02	Right switch box	1
21	Q405B820H08R	Wrie egis	1
22	J2840550002R	Button spring	1
23	Q284007A874	Button	1
24	Q195879P954	Left cover washer	1
25	Q846K27A860	Top decorative block	1
26	Q846Z59PA30	Handle	1
27	J0010001022R	Screw/ST4*16*1.3	12
28	Q195765P954	Right cover washer	1
29	Q846614PA30	Cover	1
30	G8460220001	Fillter	2
31	Q846B39PH02	Right airtake window	1
32	Q846K29AH01	Front decorative block	1
33	2A690027R	Motor	1
34	D5000100004R	Closed-end-wire-connector	2
35	J0150000998R	Star lock	1
36	Z0800000030	Washer	1
37	X8370940001R	Belt	1
38	Q819D961B49R	Motor plate	1
39	J2510000022R	Motor pulley	1
40	J0150000412R	Circlip	1
41	Q256B15AB01	Bearing"s cover	1
42	J0160000056	Bearing	1
43	Q846B38PH02	Left decorate cover	1
44	D1A640B5001R	Cable	1

45	A8370990001R	Lead	1
46	J0020000398R	Square bolt	2
47	A4054650002R	Knob	2
48	J0020000395R	Tone nut	2
49	Q256D720H02	Knob hool	1
50	J2470000093R	Down tobe	1
51	Q438741PH02	Limit wire clip	2
52	J4380000002R	Ring brake	1
53	J0160000299R	Bearing	1
54	J0010000896R	Screw	9
55	A8372040001R	Pulley insert mould	2
56	Q200D650874R	Lock of rotation	2
57	J0010000701R	Screw/ST4.2×25.57	6
58	Q200K220H33R	Right base of rotation	1
59	J0020000323R	Sqare tons nut	2
60	Q200K250H33R	Left base of rotation	1
61	J0020000128R	Lock blot	2
62	J2580000011R	Flexibility cylindrical pin	2
63	J0200000082R	Lock washer	2
64	Q195885P611	Safty board	1
65	Q405D791874R	Knob of lock	2
66	J1950360001R70C	Spring	1
67	Q837D67PH02	Right grass box	1
68	Q837A75PH02	Letf grass box	1
69	J0090000401R	Back wheel's axis	1
70	Q8376100H33R	Set square	1
71	Q837528AH01	Linker	1
72	J1970690001R	Spring	1
73	Q837D68PH02	Wheels-210	2
74	J0320000014R	Bearing ring	2
75	Q896573PH02	Front wheels cover	2
76	Q837K28PH02	Front wheels deck	2
77	Q896719P613	Operation cover	1
78	Q197F29P613	Wheels cover-160	2
79	Q197746PH02	Wheels deck-160	2
80	J0320000015R	Bearing ring	2
81	Q197D68PH02	Wheels-160	2
82	Q197D540H10R	Move axes	2
83	Q8371680H33R	Set square	1
84	Q200K04PH02	Left shift high board	1
85	MQ2006260874	Roperation pole	1
86	Q200K05PH02	Right shift high board	1
87	A8370940001R	Blade support	1
88	J2420000107R	Blade	1
89	J0200000090R	Washer/Φ8×Φ19×1.5	1

90	J0020000252R	Screw/M8x1x25	1
91	Q837G100H18R	Block	1
92	J0090000400R	Front wheel axes	1
93	Q837438PH02	Deck	1
94	J0130000023R40	Patch brake	4
95	J6330680001R	Spring brake	4
96	J4390000001R	Block brake	4
97	Z0470000001	Cork brake	4
98	J0160000296R	Bearing/6003Z	1

No the part