



1	foam pipe	1
2	upper handrail	1
3	stop lever	1
4	handrail stopper	2
5	Rope Guide	1
6	Cap nut	1
7	Bolt	1
8	Brake Cable Assy plate	1
9	Self-locking nut	1
10	brake cable	1
11	Cross recessed Pan head tapping screws	2

12	Half round head square	2
	neck bolts	
13	flat washer	2
14	knob	2
15	Hexagon nut	2
16	right lower handrail	1
17	left lower handrail	1
18	fastener	2




1	petrol engine	1
2	deck	1
3	front protection board	1
4	Cross recessed Pan head tapping screws	3


5	Bolt	3
6	Chassis bushing	3
7	mulching plug	1




1	wheel height adjust handle assy	1
2	wheel height adjust handle assy	1
3	sheath of height adjustment handle	2
4	wheel assy.	2
5	flat washer	4
6	Hex lock nut	2
7	outer cover of hub	2




1	wheel height adjust handle assy	1
2	wheel height adjust handle assy	1
3	sheath of height adjustment handle	2
4	wheel assy.	2
5	wheel axle sleeve	4
6	flat washer	4
7	pin	2
8	outer cover of hub	2
9	flat washer	2



1	top of grass box	1
2	protection board of grass bag	1
3	bottom of grass box	1
4	ross recessed Pan head tapping screws	6
5	Cross recessed small Pan head screws	2
6	Cap nut	2
7	rear discharge cover	1
8	Shaft for rear discharge cover	1
9	cover spring	1



1	in blade adapter	1
2	alu Blade Adapter	1
3	Blade	1
4	blade washer	1
5	blade bolt	1



no.	english description	Qty
1	Cap nut	3
2	Gasket	10
3	starter assy.	1
4	decoration board	1
5	Blower Housing	1
6	Hex flange nuts	1
7	starter hub	1
8	Blower Housing Bush	3
9	fan	1
10	Special bolt I	1
11	Special bolt II	1
12	Special bolt III	1
13	flywheel assy	1
14	Bolt	7
15	Respirator Cover Plate Assy	1
16		1
17	ss recessed small Pan head scr	e 1
18	spring washer	1
19	espirator spring steel valve eleme	1
20	oil filter net	1
21	Blower board	1

crankshaft box assy. detent assy. Bolt ignition assy. spacing pin spark plug IntakeValve Exhaust Valve cyclinder head assy.

32	Dual-head bolts	2
33		1
34	muffler assy.	1
35	muffler cover assy.	1
36	Self-locking nut	2
37	locking bolt	3
38	locking bolt	1
39		1
40	cylinder head cover	1
41	cylinder head cover	1

Bolt And nuts Valve adjustment nut Rocker of Valve Spring Coil of Intake Valve valve spring valve rocker arm support push rod director plate push rod Dual-head bolts Air Inlet Pipe prime button II carburetor assy. oil seal rolling bearing crankshaft assy. connecting rod assy. Piston Pin circlip Piston

64	piston pin	1
65	Bushing Ring	1

	2
67 Piston Ring II	
	1
68 Piston Ring I	1
69 Lubricating Gauge Assy	1
70	1
71 inlet fuel pipe	1
72	1
73 fuel tank cap	1
74 fuel tank cap sponge	1
75 Fuel Tank Cap seal gasket	1
76 Bolt :	2
77 Cushion Blocking gasket	4
78 fuel tank body	1
79 right bracket of fuel tank	1
80 Self-locking nut	2
81 left bracket of fuel tank	1
82	1
83 fuel pipe lock clamp I	1
84 inlet fuel pipe	1
86 fuel pipe lock clamp II	1
87 rate-limiting rocker arm shaft	1
88 oil seal	1
89 R type pin	1
90 clip	1
91 single phrase throttle assy.	1

92	Handspike of Valve	1
93	valve spring	1
94	throttle rocker arm	1
95	valve spring	1
96	bolt	1
97	Hex flange nuts	3
98	Air Filter Pedestal	1
99	waste pipe	1
100	air fiiler bush	2
101	Exhaust Gas Cover Board	1
102		1
103		1
104	Air Filter Upper Cover	1
105		1
106	spacing pin	2
107	Oil drain bolt	1
108	Oil drain bolt gasket	1
109	Crank box cover	1
110	oil seal	1
111	Bolt	1
112	Bolt	6
113	pin	2
114	nynon camshaft assy.	1
115	Sliding Sleeve	1
116	rete-limiting gear assy.	1

117	Gear Shaft circlip	1
118	Bolt	1
119	rate-limiting gear shaft clamp	1
120	rate-limiting gear shaft	1

122 klínek strváku