



RPM 4640 Pro




Ref.No.	Parts No.	Description	Qty
8	GB97.1-06	Washer 6	2
9	18.6-04	Handle Grip	1
10	2203003	Bracket	1
11	2003101	Blade Control Handle	1
13	XSZ56-1-15	Bolt	2
14	GB923-06	Acorn Nut M6	1
15	GB820-06040	Screw M6*40	1
16	2003201	Drive Clutch Lever	1
17	GB6182-06	Nylon Insert Lock Nut M6mm	1
18	WORD18.6-05B	Guy Hook	1
20	2100625	Cable Unit	1
21	2003002D	Upper Handlebar	1
22	2011031	Cable Clamp	1
26	1850006B	Knob Nut	4
27	1813301	Lower Handlebar	1
29	GB801-08040	Square Neck Bolt M8×40mm	2




Ref.No.	Parts No.	Description	Qty
8	GB97.1-06	Washer 6	2
17	GB6182-06	Nylon Insert Lock Nut M6mm	8
30	GB6182-08	Looknut M8	7
31	2100369	Torsion Spring	1
32	GB16674.1-06020	Bolt M6×20	1
33	GB93-06	Washer 6	1
34	GB96-06	Washer 6	1
35	GB91-02016	Pin2×16	2
37	2100350	Rod, Rear Cover	1
38	2100466	Rear Cover	1
41	1822004	Left Bracket	1
42	1812004	Rear Cover Bracket	1
44	GB5285-55190	Self Tapping Screws St5.5*19	7
47	1800019	Mulching Plug	1
49	1800001A	V-Belt Z762	1
51	GB16674.1-08040	Square Neck Bolt M8×40mm	3
52	2100012	Wing Nuts	1
53	1813011	Guard	1
54	GB97.1-08	Washer 8	3

55	2000019	Anti Rotation Bracket	1
56	1813810	Deck	1
57	1813012	Mulch Cover	1
58	1800017	Side Discharge Chute	1
59	2200021	Torsion Spring	1
60	2213000	Mounting Bracket, Discharging Chute	1
61	1812005A	Height Adjustment Rack	1
62	GB16674.1-06016	Hex Hd. Flange Bolt M6X16mm	6
65	4LZ2.16.4-04	Rubber Ring	1
67	1822006	Right Bracket	1
68	GB801-08016	Square Neck Bolt M8X16mm	4
69	1811023	Guard	1
135	1813006	Grass Comb	1
138	GB5285-55130F	Self Tapping Screws St5.5X13F	3
150	2200058	Belt Cover,Right	1
151	2200057	Belt Cover,Left	1




Ref.No.	Parts No.	Description	Qty
17	GB6182-06	Nylon Insert Lock Nut M6mm	9
62	GB16674.1-06016	Hex Hd. Flange Bolt M6X16mm	9
72	2011720A	Handle	1
73	2012701A	Knob	1
74	2012703	Pressure Spring	1
75	GB879-02012	Spring Pin	1
76	1804200	Rear Axle Assembly	1
77	GB97.1-12	Washer 12	4
78	GB955-12	Washer 12	4
79	84907	Gear Box	1
80	GB896-09	E-Clip 9mm	2
81	01110	Rear Wheel 11"	2
82	2200033	Pinion Gear, Right	1
83	0110001	Cover	2
84	XSZ56-2-06	E-Clip 19mm	2
85	2207002B	Bearing Housing	2
86	2012710	Handle, Rear	1
87	2207001	Bushing	2
88	2007006	Bushing	1


89	GB16674.1-06020	Bolt M6×20	2
90	2000086	Slice Pillow	2
91	00800	Wheel 8"	2
93	1809320	Front Shaft Assembly	1
96	2200032	Pinion Gear, Left	1
97	2007401	Bushing	4
98	GB879-05016	Spring Pin 5×16mm	2
99	GB16674.1-08016	Square Neck Bolt M8X16mm	4
117	2201002	Nylon Bearing 1/2"	8
118	00801	Hub Cap	2
119	01111	Hub Cap	2
120	WORD18-01	Nylon Bearing 1/2"	4
121	XSZ56-2-08	Roll Pin	2
140	1805000	Haul Shank Seam	1
141	2200053	Tension Spring	1
142	XSZ56-1-17	Hair Pin	2
143	1812009	Transmission Tension Spring	1
144	2100496	Bracket Plate	1



Ref.No.	Parts No.	Description	Qty
101	1819001	Bushing	1
102	1819300	Blade Adaptor Pulley	1
103	XSS46-01D	Blade	1
104	XSZ56-2-17	Washer	1
105	WORD18-08A	Bolt 3/8-24UNFx1-3/4	1




Ref.No.	Parts No.	Description	Qty
126	2100463A	Grass Bag Handle	1
127	2100446A	Access Plate	1
128	GB879-25130	Spring Pin2.5X13	2
129	2100447A	Grass Bag Cover	1
130	2012611	Bag Frame	1
131	1806520C	Fabric Bag	1




CRANK CASE

Pozice	Obj.číslo	Popis	Množství
1	380020070-0001	Hexagon shaft shoulder bolt	4
2	120230118-0001	Cylinder head cover	1
3	120250045-0001	Gasket for cylinder head cover	1
4	270960014-0001	Spark plug	1
5	110810363-0001	Crankcase body	1
6	380650335-0001	Oil seal	1
7	380140067-0003	Hexagon bolt with flange	3
8	110840041-0001	CAP,BREATHER CHAMBER	1
9	110850030-0002	PACKING, BREATHER CHAMBER	1
10	140250026-0001	Leaf valve	1
11	380140039-0003	Hexagon bolt with flange	1
12	380850016-0001	Stay stud	1
13	380850010-0001	Stay stud	2
14	380140077-0005	Hexagon bolt with flange	1




Pozice	Obj.číslo	Popis	Množství	
15	293030023-0001	Engine brake	1	
16	381140582-0001	Tension spring	1	
17	380180210-0001	Stud	2	
18	380140100-0003	Hexagon bolt with flange	1	
19	110690125-0002	Oil rule combination	1	
20	380180147-0001	Stud	2	
21	380822360-0001	Bushing	1	
22	160200082-0001	Side plate	1	
23	160200075-0001	Side plate	1	




CRANKCASE COVER

Pozice	Obj.číslo	Popis	Množství	
1	380140103-0004	Hexagon bolt with flange	9	
2	110820198-0001	Crankcase cover	1	
3	380650347-0001	Oil seal	1	
4	171630031-0001	Speed regulating arm	1	
5	380450527-0001	Flat washer	1	
6	380650338-0001	Oil seal	1	
7	381350004-0001	Pin clip	1	
8	380600241-0001	ocation pin	2	
9	171750039-0001	Components of governor gear	1	
10	380140167-0002	Hexagon bolt with flange	1	




CRANKSHAFT / PISTON

Pozice	Obj.číslo	Popis		Množství
1	130070257-0001	Piston ring combination		1
2	130030303-0001	Piston		1
3	130060030-0001	Piston pin		1
4	380560055-0001	Steel cable baffle ring		2
5	130150142-0001	Connecting rod		1
6	130290672-0001	crankshaft		1
7	130230061-0001	Timing driving wheel		1
8	380620030-0001	Key		1
9	380620119-0001	Key		1




CAMSHAFT

Pozice	Obj.číslo	Popis	Množství	
1	140450060-0001	Valve rocker combination	2	
2	140710013-0002	Plate, push rod guide	1	
3	140670028-0001	Push rod	2	
4	140690021-0001	Lifter, Valve	2	
5	140020174-0001	Camshaft assy	1	
6	140380020-0001	Retainer, valve spring	2	
7	140340039-0001	Inner spring of valve	2	
8	140400016-0001	Valve oil seal	2	
9	500550034-0001	Valve Kit	1	




STARTER

Pozice	Obj.číslo	Popis	Množství
1	160210165-0001	Fan cover comp.	1
2	193490527-0001	Manual starting assembly	1
3	193690040-0002	Starter decoration cover	1
4	380370066-0001	Hexagon nut with flange	3




CARBURETOR

Pozice	Obj.číslo	Popis		
			Množství	
1	170430148-0001	Carburetor gasket	1	
2	170440126-0002	Heat insulating pad for carburetor	1	
3	170450006-0001	Heat insulating plate for carburetor	1	
4	170022470-0001	Carburetor	1	
5	170430183-0001	Carburetor gasket	1	




FLYWHEEL / IGNITION COMP

Pozice	Obj.číslo	Popis	Množství
1	270920421-0001	COIL ASSY.,IGNNTION	1
2	380140103-0004	Hexagon bolt with flange	1
3	270020232-0002	FLYWHEEL COMP	1
4	380370051-0001	Hexagon nut with flange	1




AIR CLEANER

Pozice	Obj.číslo	Popis	Množství
2	180070264-0001	Air filter casing cover	1
3	180130178-0001	Air filter element	1
4	180280128-0001	Air filter seat	1
5	173270002-0001	Starting valve fixture	1
6	170260008-0001	primer valve	1
7	380741304-0002	Breather tube	1
8	380370066-0001	Hexagon nut with flange	2




CONTROL

Pozice	Obj.číslo	Popis		
			Množství	
1	380140167-0002	Hexagon bolt with flange	1	
2	171590041-0001	Throttle rod	1	
3	171620033-0003	Speed regulating bracket	1	
4	171600107-0001	Governing spring	1	
5	171680164-0001	Throttle handle combination	1	



MUFFLER

Pozice	Obj.číslo	Popis	Množství	
1	180660077-0001	Muffler gasket	1	
2	180572585-0001	Muffler	1	
3	180960204-0001	Muffler guard shield	1	
4	380370048-0001	Hexagon nut with flange	2	



FUEL TANK

Pozice	Obj.číslo	Popis	Množství	
1	170490299-0001	Tank	1	
2	170870156-0001	Tank cover	1	
3	170010017-0001	Fuel filter	1	
4	380140077-0005	Hexagon bolt with flange	2	
5	380750234-0002	Oil tube	1	
6	380950190-0001	Pipe clip	2	
7	170620016-0001	Rubber lagging for pouring orifice	1	