


Spare parts list for RPB260 transmission			
Pos no	Reference no	Description	Dosage
2-1	61270030004	GEAR CASE ASS'Y	1
2-2	03120020002	Stop Ring 26	1
2-3	03120010001	Stop Ring 10	1
2-4	03090010015	Bearing 6000-2RS/P5	2
2-5	02020090063	Pinion	1
2-6	03020030014	Screw M5x25	1
2-7	03020030021	Bolt M6x12	2
2-8	70070010008	Gear Case	1
2-9	02020160080	Safety Guard	1
2-10	03020020018	Screw M5x12	3
2-11	03090010013	Bearing 6000/P5	1
2-12	02020090012	Gear	1
2-13	02020090029	Gear Shaft	1
2-14	03090010014	Bearing 6002-2RS/P5	1
2-15	03120020001	Stop Ring 32	1
2-16	02020100020	Holder A	1
2-17	02020100012	Holder B	1
2-18	03040050014	Washer 10	1
2-19	03030010008	Left Nut M10x1.25	1
2-20	03060020004	Pin 2x16	2
2-21	61270020010	CLUTCH COMP.	1
2-22	02020050040	CLUTCH DRUM COMP.	1
2-23	03120020004	Stop Ring 35	1
2-24	03090010012	Bering 6202-2RS/P5	1
2-25	03120010005	Stop Ring 15	1
2-26	70070060032	Clutch Case	1
2-27	02080020104	Rubber Cover	1
2-28	03010010058	Screw M5x25	8
2-29	70070080038	Clamp B	1
2-30	70070080039	Clamp A	1
2-31	03010010060	Screw M6x20	4
2-32	70030180133	Harness Clamp	1
2-33	70030160007	Clamp	1
2-34	03040030002	Washer 5	1
2-35	03010060053	Screw M5x20	1
2-36	02010010091	Pipe(26*1.5*1500)	1
2-37	02020060006	Drive Shaft (1534mm)	1
2-38	02040010003	Oil-Bearing (8*14*14)	6
2-39	02080020006	Rubber Cover	6
2-40	70080080010	lever ass'y	1
2-41	03010040037	SCREW ST2.9x10	1
2-42	70030070003	BUTTON	1
2-43	02020110044	SPRING	1

2-44	70030070092	LOCKPIN	1
2-45	70030070051	HANDGRIP	1
2-46	02020110028	SPRING	1
2-47	70030070167	BOX,RIGHT	1
2-48	03010040029	SCREW ST2.9x18	2
2-49	03010010064	SCREW M5*27	1
2-50	02050040048	CABLE COMP.	1
2-51	03030010004	NUT M6	2
2-52	01040030002	TUBE	1
2-53	02050050092	STOP BUTTON COMP.	1
2-54	70030070192	HANDGRIP	1
2-55	02020110029	SPRING	1
2-56	70030070219	BOX,LEFT	1
2-57	03030060008	NUT M5	1
2-58			
2-59	70070080055	CAP,UPPER	1
2-60	02020160512	LEFT HANDGRIP	1
2-61	02080020097	RUBBER COVER	1
2-62	02020160462	RIGHT HANDGRIP	1
2-63	70070080053	BRACKET	1
2-64			
2-65			
2-66	70070080054	CAP LOWER	1
2-67			
2-68	02050220003	Nylon Cutter Head	1
2-69	03030010013	GB6170 M5	2
2-70	03010010056	Screw M5*14	2
2-71	70030030539	Bracket	1
2-72	03010010062	Screw M5*20	2
2-73	61270070004	Harness Ass'y	1
2-74	70030030385	Safety Guard	1
2-75	02010030001	Spacer	2
2-76			
2-77			
2-78	03010110124	Screw M5*20	4
2-79			
2-80	70030030056	Blade	1
2-81	03010040025	Screw ST4.2x13	2
2-82	02020070102	Blade	1
2-83	02110030022	Wire Clamp Band	2
2-84	02050060020	Harness Ass'y	1
2-85	02060040025	Blade	1
2-86	02110030004	Blade guard	1
2-87	02040030003	lock	2
2-88	02020160293	shaft jion	1
2-89	70070090016	pipe jion	1

2-90	03040050047	washer 10	1
2-91	03060030005	pin	1
2-92	70030180089	bolt	1
2-93	03010010025	bolt(M6x35)	1
2-94	03040020016	Washer 6	1
2-95	03050010013	Washer 6	1
2-96	02020060036	shaft	1
2-97	02010010072	pipe	1
2-98	03020020053	Screw M5X12	1
2-99	03010040074	Screw ST4.2x20	1



Spare parts list for RPB260 Engine			
Item	Part No.	Description	Qty
1	03010110120	Screw M5x12	1
2	70030030853	Top Cover	1
3	03020020055	Gb/T9074.4 M4*12	1
4	03010010062	Screw Assy M5x20	4
5	70070130032	Cylinder	1
6	03130010013	Spark Plug Rcj6Y	1
7	02070010032	Gasket,Cylinder	1
8	02020020003	Ring,Piston	2
9	02010020005	Piston	1
10	02020150002	Stop Ring	2
11	02020010004	Pin,Piston	1
12	02020030017	Piston Pin Retainer	2
13	03090020018	Needle,Bearing	1
14	02020120023	Crank Shaft Comp	1
15	03090010028	Gb/T276 6001/P5	2
16	03100010009	Oil Seal 12*22*7	2
17	03060010002	Pin	4
18	70070050038	Rear Crankcase	1
19	02050100015	Start Pull	1
20	02050070090	Starter	1
21	03020020029	Gb/T9074.4 M4*16	5
22	03070010001	Key3X3.7X12	1
23	02070010119	Gasket,Crankcase	1
24	70070050039	Front Crankcase	1
25	03010010058	M5*25	4
26	02050030020	Magneto Rotor	1
27	03030020003	Gb6171 M8*1 白色	1
28	03040050052	Φ6*15*1.2	2
29	02050160002	Clutch Assy	1
30	03040050042	Washer	2
31	02020130001	Clutch Step Screw	2
32	70070030026	Fan Cover	1
33	70030030164	Guide Plant	1
34	03040020012	Gb/T97.1 4	2
35	02070010048	Space ,Housing	2

36	02050030229	Ignition ,Coil	1
37	03020020054	Gb/T9074.4 M4*20	2
38	02050050213	Stop Core Comp	1
39	02080030042	Rubber	1
40	02070010162	Gasket,Muffler	1
41	02050010015	Muffler	1
42	03050010008	Gb/T93 8镀白锌	1
43	03040020018	Gb/T97.1 8 镀白锌	1
44	03010010077	M5*55 (12.9级)	2
45	02070010019	Gasket,Cylinder Side	1
46	70030020016	Insulator	1
47	03020020012	Gb/T9074.4 M5*20	6
48	02070010071	Gasket,Carburetor	1
49	02050020101	Carburetor	1
50	70080120007	Air Cleaner Cover	1
51	03020020044	Gb/T9074.4 M5*55	2
52	02090010011	Air Element	1
53	70030040225	Cleaner Outside Cover	1
54	02110030079	Knob	1
55	02110020026	Fuel Tank Cap Assy	1
56	61330010017	Inlet Fule Pipe	1
57	61330010018	Outlet Fuel Pipe	1
58	02050120002	Cleaner	1
59	03020020027	Gb/T9074.4 M5*16	3
60	03040050022	Φ5*15*1 (非标)	3
61	70050030170	Fuel Tank	1