



Spare parts list for REH6261RH			
Pozice	Obj.číslo	Popis	Počet ks
1	HTEG52A01	Aluminium layering	1
2	HTEG52A02	Block	1
3	HTEG52A03	Four angle flange bolt M5*14	1
4	HTEG52A04	Liner	1
5	HTEG52A05	Insert ring	1
6	HTEG52A06	Upper blade	1
7	HTEG52A07	Lower blade	1
8	HTEG52A08	Head protection	1
9	HTEG52A09	Cross recessed pan head screw ST4*12	1
10	HTEG52A10	M5 six angle lock nut	1
11	HTEG52A11	Scabbard	1
12	HTEG52A12	Blade washer	1
13	HTEG52A13	Cross recessed pan head screw ST4*16	1
14	HTEG52A14	Cross recessed pan head screw ST4*16	1
15	HTEG52A15	Bottom cover	1
16	HTEG52A16	Cable clamp	1
17	HTEG52A17	Sheath	1
18	HTEG52A18	Power cord	1
19	HTEG52A19	Right casing	1
20	HTEG52A20	Cross recessed pan head screw ST4*20	1
21	HTEG52A21	Right trim cover	1
22	HTEG52A22	Main button	1
23	HTEG52A23	Capacitance	1
24	HTEG52A24	Main button spring	1
25	HTEG52A25	inductance	1
26	HTEG52A26	Cross recessed pan head screw ST3*10	1
27	HTEG52A27	Wire guide	1
28	HTEG52A28	Wire	1
29	HTEG52A29	Lever	1
30	HTEG52A30	Pull plate	1
31	HTEG52A31	Inching double switch	1
32	HTEG52A32	Plate spring	1
33	HTEG52A33	Soft collar	1
34	HTEG52A34	Soft collar spring	1
35	HTEG52A35	Soft shaft wire	1
36	HTEG52A36	Become warped plate	1
37	HTEG52A37	R * 40 (type B) cylindrical pin	1
38	HTEG52A38	Secondary button	1
39	HTEG52A39	bracket	1
40	HTEG52A40	Cross head screw ST4*20	1
41	HTEG52A41	Bracket left cover	1
42	HTEG52A42	Protection cover	1
43	HTEG52A43	Bracket right cover	1
44	HTEG52A44	Cross head screw ST4*12	1
45	HTEG52A45	At the upper cover	1

46	HTEG52A46	Integral left hand handle	1
47	HTEG52A47	Rotating button	1
48	HTEG52A48	Rotating button spring	1
49	HTEG52A49	The upper cover	1
50	HTEG52A50	Left casing	1
51	HTEG52A51	Upper cover	1
52	HTEG52A52	Cross head screw ST3*10	1
53	HTEG52A53	Carbon brush assembly	1
54	HTEG52A54	Brush holder	1
55	HTEG52A55	Brush insert	1
56	HTEG52A56	Deep groove ball bearings 607	1
57	HTEG52A57	rotor	1
58	HTEG52A58	Deep groove ball bearings 608	1
59	HTEG52A59	stator	1
60	HTEG52A60	Cross recessed pan head screw ST4*25	1
61	HTEG52A61	Lower cover of motor	1
62	HTEG52A62	Cross recessed pan head screw M4*47	1
63	HTEG52A63	O5 flat cushion	1
64	HTEG52A64	Center support	1
65	HTEG52A65	Book shim	1
66	HTEG52A66	Needle roller bearing HK808	1
67	HTEG52A67	Driven gear	1
68	HTEG52A68	Eccentric lower plate	1
69	HTEG52A69	External Circlips	1
70	HTEG52A70	Dowel pin	1
71	HTEG52A71	Non-standard nut	1
72	HTEG52A72	Locating sleeve	1
73	HTEG52A73	Rotate button to stop	1
74	HTEG52A74	Button to stop the spring	1