



## Spare parts list for REV3815

Position no	ERP	English Name	Dosage
1	J0010001032R	Bolt/M4*10	2
2	J4650000002R	Trigger Level	1
3	J2470000090R	Upper handle	1
4	Q990K360Y16	Cover handle	1
5	Q990885PY16	Safty flap	1
6	Q284007A874	Button	1
7	D3039000001R	Switch	1
8	Q284F241H33R	Right brace	1
9	Q284F231H33R	Left brace	1
10	J2840550002R	Spring	1
11	Q284D88PH02	Right switch box	1
12	J280360001R	Spring	1
13	Q2849430H33R	Trigger	1
14	Q405B820H08R	Cable jacket	1
15	Q284B700B25R	Double line block	1
16	Q284D87PH02	Left switch box	1
17	Q284F50PH02	Right fulcrum	1
18	J2840360002R	Spring	1
19	Q284F49PH02	Left fulcrum	1
20	A9902790006R	Grassbox	1
21	D1A640B5001R	Cable	1
22	A9900990001R	Cable mouldle	1
23	J2470000092R	Middle handle	2
24	J0020000384R	Bolt	4
25	J0150000044R	Dish	4
26	A4054650002R	Knob	4
27	J0020000005R	Nut	4
28	Q9908360698	Decorate block	1
29	J0010000665R	Bolt	44
30	Q990614P874	Cover	1
31	Q438741PH02	Hook	2
32	J0350000154R	Grassbox lever	1
33	Q9907200Y16	Back wheel cover	2
34	J0320000015R	Hub cap	6
35	Q197746PH02	Wheel mount 160	2
36	Q197D68PH02	Wheel 160	2
37	J0030000019R	Dish	2
38	Q256D720H02	Cable hook	1
39	J0090000463R	Rear axle	2
40	Q405D791874R	Lock knob	2
41	J0020000128R	Bolt	2
42	J0200000082R	Dish	2
43	Q200D650874R	Rotate hlook	2

44	Q990K220H33R	Right rotate seat	1
45	J0020000323R	Nut	2
46	D5000100004R	Connect cap	1
47	J9900360002R	Spring	1
48	J4610000001R	Axle	1
49	J2470000091R	Lower handle	1
50	Q990K250J33R	Left rotate seat	2
51	J2580000011R	Pin	3
52	J0010000896R	Bolt	1
53	2AH60001R	Motor	1
54	J2510000019R	Mptor pully	1
55	X8962650001R	Belt	1
56	J3820000004R	Axle	1
57	J2580000045R	Pin	1
58	J0160000319R	Bearing	1
59	Q8966150B25R	Cincture	1
60	J0200000236R	Dish	1
61	J0160000004	Bearing	1
62	J0150000412R	Clip	1
63	Q896T120B25R	Gear cover	1
64	G9900220001	Filter	2
65	J3420000011R	Fixation block	1
66	Q1313070B25R	Line block	1
67	Q9907190Y16	Front wheel cover	2
68	Q1977460H02	Wheel mount 140	2
69	Q990F46PH02	Wheel 140	2
70	Q197G100H18R	Weight block	1
71	Q990438PH02	Deck	1
72	Q990633AG98	Height knob	1
73	J0200000215R	Dish	1
74	J0150000498R	Dish	1
75	Q990B210B10R	Plastic nut	1
76	Q9908800B10R	Plastic bolt	1
77	J0160000166R	Bearing	1
78	J0030000026R	Dish	1
79	J0020000231R	Nut	1
80	J1810000017R	Main axle	1
81	J1980000005R	Dish	1
82	J0090000407R	Front axle	1
83	J0100000062R	Clip	1
84	G9900220002	Filter	1
85	J0150000412R	Pin	2
86	J0010001230R	Nut	2
87	Q5898150H33R	Bearing shell	1
88	A9900940004R	Blade moudle	1

89	Q990F48PH02	Fixation cover	1
90	J9900360003R	Spring	22
91	Q990L58PH02	Fixation block	11
92	J0320000014R	Hub cap	2
93	J2030000009R	Hex wrench	1