




RPCS 2530



Spare parts list of RPCS2530

Parts no	Drawing NO	English Name	Qty
001	YD2500-92102	Nut M8X1/GB/T 6177	1
002	YD2500-15110	Flywheel	1
003	YD2500-94601	Woodruff Key3X3.7*10/GB/T 1099	1
004	YD2500-95011	Small Seal Oil 12×22×4.5/GB/T 9877.1	1
005	YD2500-96011	6001 Bearing-Ball/GB/T 276	2
006	YD2500-90121	Screw M5*20/GB/T 6191	4
007	YD2500-13109	Support-Bearing	1
008	YD2500-95012	Big Seal Oil 12×28×6/GB/T 9877.1	1
009	YD2500-14100	Crank Shaft Assy	1
010	YD1800-14803	Ring-Bearing	2
011	YD2500-96111	Bearing-Needle K081109/JB2581	1
012	YD2500-14211	Piston	1
013	YD2500-14002	Ring Snap	2
014	YD2500-14001	Pin-Piston	1
015	YD2500-14311	Ring-Piston	1
016	YD2500-26151	Write-Stop	1
017	YD2500-97001	Screw M4*20/GB/T 70.1	2
020	YD2500-26110	Ignition Assy	1
021	YD2500-26131	Pad-Electric Ignition	2
022	YD2500-26117	Wahser	1
023	YD2500-12111	Cylinder	1
024	YD2500-26200	Spark Plug M7	1
025	YD2500-17008	Gasket-Worm Φ 10X ϕ 18X1	1
026	YD2500-16111	Hose-Air	1
027	YD2500-90201	Screw M4X14/GB/T 2672	2
028	YD2500-21001	Washer-Muffler	1
029	YD2500-21110	Muffler Assy	1
030	YD2500-21101	Cover-Muffler	1
031	YD2500-90027	Screw-Muffler M5*40/GB/T 70.1	2
032	YD2500-91324	Screw St4.2*12/GB/T 845	2
033	YD2500-27331	Cover-Top	1
034	YD2500-27401	Paper Gasket	1
035	YD2500-26155	Wire-Ground	1
036	YD2500-90224	Screw M5*20/GB/T 2672	5
037	YD2500-18432	Tie-In-Hose Oil	2
038	YD2500-18431-1	Oil Return Pipe 1 Φ 2.5X ϕ 4.5X100	1
039	YD2500-18101	Hose Fuel	1
040	YD2500-18104	Support-Hose Oil	1
041	YD4500-18433	Connect Pipe	1
042	YD2500-18431-2	Oil Return Pipe 2	1
043	YD4500-18105	Spring-Hose Fuel	1
044	YD2500-18103	Filter	1
045	YD2500-18015	Cover-Balance	1

046	YD2500-18014	Balance	1
047	YD2500-18013	Cover-Balance	1
048	YD2500-18011	Connect Balance $\Phi 3.5 \times \Phi 6 \times 15$	1
049	YD2500-91322	Screw St4.2X12/GB/T 845	2
050	YD2500-27121	Stop	1
051	YD2500-18032	Cap-Fuel Oil	1
052	YD2500-18033	Washer-Fuel Oil Cap	1
053	YD2500-17111	Holding-Oil Cap	2
054	YD2500-17112	Cap-Hose Oil	1
055	YD2500-17113	Washer-Hose Oil Cap	1
056	YD2500-18410	Oil Vaculot	1
057	YD2500-13901	Tank Case	1
058	YD2500-13001	Chain Catcher	1
059	YD2500-27119	Gasket $\Phi 6 \times \Phi 20 \times 3$	2
060	YD2500-22692	Sponge-Oil Hole Plate	1
061	YD2500-22931	Plate-Oil Hole	1
062	YD2500-91201	Screw M4X12、GB/T 2672	2
063	YD4500-17131	Breath Nipple	1
064	YD4500-17133	Cover-Breath Nipple	1
065	YD4500-17132	Spring-Breath Nipple	1
066	YD2500-27111	Pad-Rubber	3
067	YD2500-27116	Screw	3
068	YD2500-27112	Plug-Pad	3
069	YD2500-23196	Support-Locking	1
070	YD2500-91001	Screw St4.2X14/GB/T 891.2	3
071	YD2500-27431	Pothhok	1
072	YD2500-91323	Screw St4.2X14/GB/T 845	1
073	YD2500-92201	Nut M5/GB/T 41	1
074	YD2500-93011	Big Washer $\Phi 5 \times 15 / \text{GB/T } 96.1$	1
075	YD2500-24406	Cover	1
076	YD2500-24213	Pin-Trigger	1
077	YD2500-24401	Handle	1
078	YD2500-24112	Grommet-Choke Knob	1
079	YD2500-24111	Choke Knob	1
080	YD2500-24214	Lever-Trigger	1
081	YD4500-24212	Spring-Trigger	1
082	YD2500-24211	Trigger	1
083	YD2500-26190	Switch Stop	1
084	YD2500-24441	Cover-Handle	1
085	YD2500-91324	Screw St4.2X16/GB/T 845	1
086	YD2500-90226	Nut M5X45/GB/T 2672	1
087	YD2500-24001	Rod Throttle	1
088	YD2500-18200	Carburetor	1
089	YD2500-16201	Support-Air Filter	1
090	YD2500-16311	Cover-Air Filyer	1
091	YD2500-90028	Screw-Carburetor M5X45/GB/T 70.1	2

092	YD2500-16203	Sponge-Air Filter	1
093	YD2500-16301	Cover-Air Filter Sponge	1
094	YD2500-16204	Cover-Air Filter	1
095	YD2500-16302	Knob-Air Filter	1
096	YD2500-23011	Leverage	1
097	YD2500-23122	Lever-Brake	1
098	YD2500-23123	Spring-Leverage	1
099	YD2500-93012	Washer-Spring Φ 5X10/GB/T97.1	1
100	YD2500-92201	Nut M5/GB/T 889	1
101	YD2500-23031	Spring-Brake	1
102	YD2500-23121	Pin-Leverage	1
103	YD2500-23033	Bushing	1
104	YD2500-91301	Screw M5X30/GB/T 818	1
105	YD2500-92101	Nut M8/GB/T 6177	1
106	YD2500-23218	Locking	1
107	YD2500-27301	Housing Brake	1
108	YD2500-23111	Band Brake	1
109	YD2500-94011	Pin-Band Brake Φ 3X8/GB/T 119.1	1
110	YD2500-23113	Spring-Brake	1
111	YD2500-23110	Plate-Brake	1
112	YD2500-23109	Pusher-Spring(Brake)	1
113	YD2500-94013	Pin Φ 3X14/GB/T 119.1	1
114	YD2500-91321	Screw St4.2X9.5/GB/T 845	1
115	YD2500-22251	Plate-Bar	1
116	YD2500-22201	Sprocket-Chainadjusting	1
117	YD2500-22211	Screw Chainadjusting	1
118	YD2500-22212	Pin	1
119	YD2500-23013	Spring-Leverage	1
120	YD2500-23014	Support-Leverage Spring	1
121	YD2500-23108	Cover-Brake Spring	1
122	YD2500-91321	Screw St4.2X9.5/GB/T 845	4
123	YD2500-22113	Spring-Clutch	2
124	YD2500-22112	Clutch	2
125	YD2500-22111	Retainer	1
126	YD2500-22101	Washer-Clutch	1
127	YD2500-22121	Drum-Clutch	1
128	YD2500-96112	Bearing-Needle/JB/2581	1
129	YD2500-17001	Worm	1
130	YD2500-91322	Screw St4.2X12/GB/T 845	2
131	YD2500-17301	Cover-Oil Pump	1
132	YD2500-90201	Screw-Oil Pump M4X14/GB/T 2672	2
133	YD2500-93101	Washer-Spring Φ 4/GB/T 93	2
134	YD2500-93001	Washer Φ 4/GB/T 97.1	2
135	YD2500-17200	Oil Pimp Assy	1

136	YD2500-17003	Fuel Injection Nozzle	1
137	YD2500-17303	Sponge-Plug Pad	1
138	YD2500-17121	Hose Oil	1
139	YD2500-17124	Oil Filter	1
140	YD2500-20901	Support-Intake Air	1
141	YD2500-91320	Screw St4.2X8.5	1
142	YD2500-15120	Baffle-Fan	1
143	YD2500-91332	Screw St4.8X16/GB/T 845	1
144	YD2500-93011	Washer Pully Starter Φ 5X15/GB/T 96.1	1
145	YD2500-25211	Pulley-Starter	1
146	YD2500-25213	Spring Starter	1
147	YD2500-25212	Spring-Starter	1
148	YD2500-25110	Cover-Starter	1
149	YD2500-91324	Screw St4.2X16/GB/T 845	5
150	YD2500-91311	Screw St3.5X10/GB/T 845	1
151	YD2500-93001	Washer Φ 4/GB/T97.1	1
152	YD2500-27216	Pad Rubber Suppotr	1
153	YD2500-24500	Handle	1
154	YD2500-91333	Screw St4.8X16/GB/T 845	2
155	YD4500-25302	Rope Jacket	1
156	YD4500-25312	Ring-Handle	2
157	YD4500-25313	Spring	1
158	YD4500-25311	Handle-Starter	1
159	YD2500-25301	Rope-Starter Φ 2.9X850	1
160	YD2500-13002	Spike	1
161	YD2500-91221	Screw St4.8X14/GB/T 2672	2
162	YD2500-22910-12	Bar	1
163	YD2500-22300-12	Oregon Chain	1
164	YD2500-22920	Bar Cover	1
165	YD2500-90025	Screw M5X25/GB/T 70.1	1
166	YD4500-25318	Gasket-Rubber Φ 5	1
167	YD2500-92001	Nut M5/GB/T 41	1
168	YD2500-18236	Oil Hose-Carburetor	2
ZC1	YD2500-14000	Crankshaft Assy	1
ZC2	YD2500-18030	Fuel Cap Assy	1
ZC3	YD2500-19230	Oil Cap Assy	1
ZC4	YD2500-25000	Starter Assy	1
ZC5	YD2500-18010	Balance Assy	1
ZC6	YD2500-18100	Fuel Filter Assy	1
ZC7	YD2500-22110	Drum-Clutch Assy	1
ZC8	YD2500-23000	Brake Assy	1