


Model 2014





Spare parts list for RECS1840			
NO	Parts reference	En name	Dosage
1	8SBABC04-16	screw	28
2	8069-930001	back cover	1
3	8030-900001	wash 1	1
4	8053-900005	front finger guard	1
5		label	1
6		label	1
7	801-930001	left housing	1
8	8072-900001	brake block	1
9	9035-900001	carbon brush	2
10	8039-900001	brush holder	1
11	8DB-60802	bearing	1
12	8074-900003	screw	2
13	8005-900001	field	1
14	8053-900004	wind screen	1
15	8023-900002	blade cover	1
16	8013-900001	armature	1
17	8159-900001	brake wheel	1
18	8139-900001	driving disc	1
19	8SBABC04-10	screw	7
20	8072-900002	block	1
21	8047-900001	brake belt	1
22	8060-900002	extension spring	1
23	8050-900001C	hinge	1
24	8060-900001	extension spring	1
25	8SBAB04-8	screw	1
26	9WSB-04	spring washer	1
27	8030-900002	wash 2	1
28	8023-900004	bushing	1
29	8053-900006	guide bar	1
30	8053-900001	adjusting board	1
31	8038-900001	oil pipe 1	1
32	8050-900001	saw chain	1
33	8146-900001	oil pump housing	1
34	8023-900003	oil pump sheath	1
35	8025-900003	o type ring	1
36	8146-900002	oil pump core	1
37	8138-900003	pin	3
38	8038-920002	oil pipe 2	1
39	8038-900002	microswitch	1
40	8039-900002	motor support	1
41	8CC-08	retaining spring	1
42	8057-900001	bolt	1
43	8DB-600002	bearing	2
44	8020-900001	spindle	1
45	8058-900003	big gear	1
46	80B-600102	bearing	1
47	8053-900006	rubber sheath	1
48	8081-900002	cover 2	1

49	8155-900002	spiked pumper	1
50	8025-900004	rubber ring	1
51	8132-900001	sponge	1
52	8002-930001	right housing	1
53	8SEABC04-10	screw	3
54	8053-900002	Spiral plate	1
55	8069-930002	chain clamp plate	1
56	8063-900004	spring	1
57	8058-900001	knob 1	1
58	8058-900002	knob 2	1
59		label	1
60	BCC-10	retaining spring	1
61	B155-900001	Sprocket	1
62	8069-900001	Shield	1
63	8NDB-08	Locknut	1
64	8052-900002	small gear	1
65	8156-900002	Rubber cork	5
66	8032-900003	wash 3	2
67	8032-900004	wash 4	1
68	8148-900001	oil tank sheath	1
69	8025-900001	Ring	1
70	8060-900005	spring	1
71	8081-900001	filter screen stopper	1
72	8147-930001	oil tank	1
73	8025-900002	o type ring	1
74	8148-900002	rubber sheath on oil tank	1
75	8069-900003	oil tank cap	1
76	8027-900001	connecting wire	1
77	8057-930001	pull rod	1
78	8058-900003	switch button	1
79	8032-900001	switch	1
80	8033-900001	capacitor	1
81	8053-900001	cord clamp plate	1
82	8023-900001	cord sheath	1
83	8029-900001	supply cord	1