



Adjustment chain assembly

Z

Spare parts list for RECS2440

Pos. no	Factory part number	Factory Description English	Qty
1	8094-950001	front handle	1
2	8114-950002	label	1
3	8053-950003	front finger guard	1
4	8030-900001	washer 1	1
5	8001-950001	left housing	1
6	8157-950001	switch trigger	1
7	8072-900001	brake block	1
8	8SBABC04-16	screw	2
9	8009-401001	rivet	1
10	8053-401004	regulating plate	1
11	91PJ056X-C	chain	1
12	160SDEA041-B	bar	1
13	8023-900002	blade cover	1
14	8155-900002	spiked humper	1
15	8CC-10	retaining ring	1
16	8030-141003	washer 2	1
17	8155-900001	sprocket	1
18	8069-900001	dust cap	1
19	8113-950001	label	1
20	8SBABC04-16	screw	14
21	8002-950001	right housing	1
22	8030-950002	carbon brush insert	2
23	8030-950001	field insert	4
24	8027-950004	wiring 4	2
25	8033-950001	capacitor	1
26	8027-950002	wiring 2	1
27	8027-950001	wiring 1	2
28	8027-950003	wiring 3	1
29	8060-950002	spring	1
30	8057-950002	pull rod	1
31	8058-950001	side button	1
32	8032-900002	microswitch	1
33	8029-950001	supply cold	1
34	8023-900001	cors sheath	1
35	8SBABC04-12	screw	2
36	8053-900001	cold clamp plate	1
37	8130-870001	terminal strip	1
38	8060-950001	torsional spring	1
39	8113-950002	label	1
Motor assembly			
1	8036-660001	carbon brush holder	1
2	8DB-60802	bearing	1
3	8023-131001	carbon brush set	2

4	8035-950001	carbon brush	2
5	8013-950001	armature	1
6	8077-920002	woodruff key	1
7	8005-950001	field	1
8	8053-950002	wind screen	1
9	8159-900001	brake wheel	1
10	8DB620002	bearing	1
11	8023-950001	axle sleeve 1	1
12	8052-950001	small gear	1
13	8060-950004	extension spring	1
14	8050-900001C	brack hinge C	1
15	8060-900001	extension spring	1
16	8146-900002	oil pump core	1
17	8025-900003	O type ring	1
18	8023-900003	oil pump sets	1
19	8SBABC04-12	screw	2
20	8038-900001	oil pipe 1	1
21	8028-900001	rubber gasket	1
22	8146-131001	oil pump housing	1
23	8038-900002	oil pipe 2	1
24	8030-900003	washer 3	2
25	8138-950001	columns pin	3
26	8072-900002	block	1
27	8039-950001	motor support	1
28	8052-950002	big gear	1
29	8020-950002	output shaft	1
30	8DB-600102	bearing	1
31	8053-950001	cover	1
32	8SBABC04-16	screw	10
33	8025-900004	rubber ring	1
34	8148-900001	rubber sheath on oil tank	1
35	8025-900001	seal ring	1
36	8060-900005	spring	1
37	8081-900001	filter screen stopper	1
38	8023-950002	axle sleeve 2	1
39	8DB-600002	bearing	1
40	8057-900001	bolt	1
41	8147-950001	oil tank	1
42	8025-900002	O type ring	1
43	8148-900002	rubber sheath on oil tank cap	1
44	8069-131001	oil tank cap	1
45	8032-900002	microswitch	1
46	8NDN-08	hex nut	1
47	8156-900002	bakelite column	5
48	8047-900001	brake steel belt	1
49	8WSB-08	shells pad	1
50	8030-920001	washer	1
51	8SBABC04-10	screw	3
52	8SBEBEC04.2-62	field bolt	2
Adjustment chain assembly			
1	8058-401002	knob 2	1
1-1	8075-131001	inserts in nut	1
2	8053-401001	knob cover	1

3	8SBABC04-8	screw	3
4	8060-950003	spring	3
5	8128-401001	steel ball	3
6	8058-401001	knob 1	1
7	8114-950001	label	1
8	8069-950001	chain clamp plate	1
9	8053-900002	spiral plate	1
10	8SEABC04-12	screw	3
Z	DU80509K23	Right assembly	1