



sl 10 lu²



Skizze	Art.Nr.	Benennung	description
1	390 1205 012		
2	390 1205 013	Drehgriff	handle
3	390 1205 014	Gummifuß	rubber foot
4	390 1205 015		
5	390 1205 016		
6	390 1205 017		
7	390 1205 018		
8	390 1205 019		
9	390 1205 020		
10	390 1205 021		
11	390 1205 022		
12	390 1205 023		
13	390 1205 024	Handgriff	handle
14	390 1205 025	Verstellgriff	adjusting grip
15	390 1205 026		
16	390 1205 027		
17	390 1205 028	Zeiger	pointer
18	390 1205 029		
19	390 1205 030		
20	390 1205 031	Tischeinlage	table insert
21	390 1205 032		
22	390 1205 033		
23	390 1205 034		
24	390 1205 035		
25	390 1205 036		
26	390 1205 037		
27	390 1205 038		
28	390 1205 039		
29	390 1205 040		
30	390 1205 041		
31	390 1205 042		
32	390 1205 043		
33	390 1205 044		
34	390 1205 045		
35	390 1205 046		
36	390 1205 047		
37	390 1205 048	Spanngriff	clamping handle
38	390 1205 049		
39	390 1205 050		
40	390 1205 051		
41	390 1205 052		
42	390 1205 053		
43	390 1205 054		
44	390 1205 055		
45	390 1205 056		
46	390 1205 057		
47	390 1205 058		
48	390 1205 059		
49	390 1205 060		
50	390 1205 061		
51	390 1205 062		
52	390 1205 063		
53	390 1205 064	Halteglied	support bar
54	390 1205 065		
55	390 1205 066	Schraube	screw
56	390 1205 067		
57	390 1205 068		
58	390 1205 069		
59	390 1205 070		

sl 10 lu²



Skizze	Art.Nr.	Benennung	description
60	390 1205 071		
61	390 1205 072		
62	390 1205 073		
63	390 1205 074		
64	390 1205 075		
65	390 1205 076		
66	390 1205 077	Anschlag	fence
67	390 1205 078		
67-72, 2	390 1205 079	Werkstückspanner	workpiece holder
68	390 1205 080		
69	390 1205 081		
70	390 1205 082		
71	390 1205 083		
72	390 1205 084		
73	390 1205 085		
74	390 1205 086	Schraube	screw
75	390 1205 087	äußerer Sägeblattflansch	outer sawblade flange
76	390 1205 088		
77	390 1205 089		
78	390 1205 090	innerer Sägeblattflansch	inner sawblade flange
79	390 1205 091		
80	390 1205 092		
80-87	390 1205 093	Sägewelleneinheit	saw shaft device
81	390 1205 094		
82	390 1205 095		
83	390 1205 096		
84	390 1205 097		
85	390 1205 098		
86	390 1205 099		
87	390 1205 100		
88	390 1205 101		
89	390 1205 102		
90	390 1205 103		
91	390 1205 104		
92	390 1205 105		
93	390 1205 106		
94	390 1205 107		
95	390 1205 108		
96	390 1205 109		
97	390 1205 110		
98	390 1205 111		
99	390 1205 112		
100	390 1205 113	Anker	rotor
101	390 1205 114	Kohlebürsten (Satz = 2 Stück)	carbon brushes (set = 2 pcs.)
102	390 1205 115		
103	390 1205 116		
104	390 1205 117		
105	390 1205 118		
106	390 1205 119	Stator	stator
107	390 1205 120		
108	390 1205 121		
109	390 1205 122		
110	390 1205 123		
111	390 1205 124		
112	390 1205 125		
113	390 1205 126		
114	390 1205 127		
115	390 1205 128	Absaugstutzen	suction connector
116	390 1205 129	Spänesack	dust bag

sl 10 lu²



Skizze	Art.Nr.	Benennung	description
117	390 1205 130	Schraube	screw
118	390 1205 131	Gelenk	link
119	390 1205 132		
120	390 1205 133		
121	390 1205 134		
122	390 1205 135		
123	390 1205 136		
124	390 1205 137	Feder	spring
125	390 1205 138		
126	390 1205 139		
127	390 1205 140		
128	390 1205 141		
129	390 1205 142		
130	390 1205 143		
123, 129-132	390 1205 144	unterer Sägeblattschutz kpl.	lower sawblade guard cpl.
131	390 1205 145		
132	390 1205 146		
133	390 1205 147		
134	390 1205 148		
135	390 1205 149		
136	390 1205 150		
137	390 1205 151		
138	390 1205 152		
139	390 1205 153		
140	390 1205 154		
141	390 1205 155		
142	390 1205 156		
143	390 1205 157		
144	390 1205 158		
145-146	390 1205 011	Schalter	switch
147	390 1205 159		
148	390 1205 160		
149	390 1205 161		
150	390 1205 162		
151	390 1205 163	Elektronik	electronic
152	390 1205 164		
153	390 1205 165		
154	390 1205 166		
155	390 1205 167	Drehgriff	handle
156	390 1205 168		
156-158, 69, 71	390 1205 169	Werkstückspanner	workpiece holder
157	390 1205 170		
158	390 1205 171		
159	390 1205 172		
160	390 1205 173		
160-165, 63	390 1205 174	Lasert kpl.	laser cpl.
161	390 1205 175		
162	390 1205 176		
163	390 1205 177		
164	390 1205 178		
165	390 1205 179		