



pc 08



Skizze	Art.Nr.	Benennung	description
1-2, 9	390 4601 012	Handgriff kpl.	handle cpl.
3	390 4601 014	Gashebel inkl. Bowdenzug	throttle control incl. bowden cable
4	0201 2503	Scheibe	washer
5	0279 8525	Linsenschraube, M5x25	screw, M5x25
3-5	390 4601 017	Gaszug kpl. inkl. Bowdenzug	accelerator cable cpl. incl. bowden cable
6	390 4601 018	Feder (Satz = 2 Stück)	spring (set = 2 pcs.)
7	0209 8504	Sechskantmutter selbstsichernd, M6	nut, M6
8	0209 3351	Sechskantschraube M6x40	screw, M6x40
10	390 4601 022	Mutter	nut
11	390 4601 023	Gummipuffer	rubber pad
12	0201 2507	Scheibe	washer
13	0209 3152	Sechskantschraube, M10x70	screw, M10x70
14	390 4604 012	Keilriemenabdeckung	v-belt cover
15	390 4604 013	Schraube	screw
16	0201 2707	Federring, A8	washer, A8
17	390 4604 014	Keilriemen	v-belt
18	390 4601 030	Schraube	screw
19	390 4604 015	Passfeder	fitting key
20	390 4601 032	Scheibe	washer
21	390 4604 016	Keilriemenscheibe mit Fliehkraftkupplung	v-belt pulley with centrifugal clutch
24	390 4604 017	Platte	plate
25-26	390 4601 037	Benzinschlauch inkl. Kupplung	gas hose incl. coupling
27	390 4601 039	Scheibe	washer
28	390 4604 010	Motor	motor
29	390 4604 018	Mutter	nut
30	0201 2506	Scheibe	washer
31	390 4604 019	Schraube	screw
32	390 4604 020	Mutter	nut
33	390 4604 021	Grundplatte	base plate
34	0209 3364	Sechskantschraube, M8x16	screw, M8x16
35	390 4601 047	Gummipuffer	rubber pad
36	390 4601 048	Gummipuffer	rubber pad
40	390 4604 022	Schraube	screw
41	390 4601 053	Stopfen	plug
42	390 4601 054	Scheibe	washer
43	390 4604 023	Grundplatte	base plate
44	390 4601 056	Scheibe	washer
45	0209 8506	Sechskantmutter selbstsichernd, M10	nut, M10
46	390 4604 024	Gummidämpfer (Satz = 4 Stück)	rubber buffer (set = 4 pcs.)
47	390 4604 025	Welle	shaft
48	390 4601 060	Dichtung	seal
51	390 4604 026	Riemenscheibe	pulley
52	390 4601 064	Passfeder	fitting key
53	390 4604 027	Kunststoffmatte transparent	paving pad transparent
54	390 4604 028	Klemmleiste	clamp plate
55	390 4604 029	Scheibe	washer
56	0209 3383	Sechskantschraube M10x20	screw, M10x20
54-56	390 4604 030	Montageleiste kpl. (Satz = 2 Stück)	clamp plate cpl. (set = 2 pcs.)
60	390 4601 073	Sicherungsstift	locking pin
61	390 4601 074	Klemmring	clamping ring
62	390 4601 075	Rad (Satz = 2 Stück)	wheel (set = 2 pcs.)
63	390 4601 076	Radachse	wheel axle
64	390 4601 077	Lasche	link plate
65	390 4601 078	Feder	spring
66	390 4604 031	Kupplung	clutch

pc 08



Skizze	Art.Nr.	Benennung	description
67	390 4601 080	Kupplungsbelag	clutch lining
68	390 4601 081	Kugellager	bearing
69	390 4601 082	Federring	snap ring
70	390 4604 032	Riemenscheibe	pulley
71	390 4601 084	Sicherungsring	safety ring
72	390 4604 033	Scheibe	washer
73	390 4604 034	Scheibe	washer
74	390 4604 035	Haken	hook
75	390 4604 036	Anschraubplatte	plate
76	390 4604 037	Abdeckung Kugellager	bearing cover
77	390 4604 038	Scheibe	washer
78	390 4604 039	O-Ring	O-ring
79	390 4604 040	Abdeckung Kugellager	bearing cover
80	390 4604 041	Schraube	screw
81	390 4604 042	Kugellager	bearing
83	390 4604 043	Schraube	screw
84	390 4604 044	Schraube	screw
10-12, 56, 60-64	390 4601 085	Fahrwerk kpl.	undercarriage cpl.
o.Abb.	390 4604 045	Luftfilter	air filter
o.Abb.	390 4604 046	Starterkit kpl.	engine kit.
o.Abb.	390 4604 047	Zündkerzenstecker mit Kabel	sparkling plug connector with cable
o.Abb.	390 4604 048	Zündkerze	sparkling plug
o.Abb.	390 4604 049	Ein/Aus Schalter	On/Off switch
o.Abb.	390 4604 050	Tank	tank
o.Abb.	390 4604 051	Zündkerzenschlüssel mit Stift	sparkling plug key with pin
o.Abb.	390 4604 052	Öleinfüllschraube	oil filler screw
o.Abb.	390 4604 053	Schutzgitter	guard
o.Abb.	390 4604 054	Beipackbeutel	screw bag
o.Abb.	390 4604 055	Tankdeckel	fuel tank cap
o.Abb.	390 4604 056	Vergaser	carburetor
o.Abb.	390 4604 057	Auspuff	exhaust pipe